User Commands

Full Set System 1 + ENTER + User code

Part Set System 2 + ENTER + User code

Unset/Reset System User code

Omit zone 1 (or 2) + ENTER + User code + OMIT + zonenumber (repeat OMIT + zone number for other zones as required).

Omit 24 hr zone OMIT + ENTER + User code + zone number (+ zone number for other zones as required)

Change User code 4 + ENTER + Old code + Old code (the system beeps twice)+ New code (the system beeps twice)

Read Log 5 + ENTER + User code, 1 to read earlier events, 3 to read later events

ENTER to leave the log

Chime On/Off 7 + ENTER + User code

Bell Test 8 + ENTER + User code

Walk Test 9 + ENTER + User code

ENTER to end the test